

Gas Heater – Foldbar

Brugermanual



LQ-H002F

MADE IN P.R.C

Læs venligst instruktionerne før gas heateren tages i brug

Mange tak for at købe en gas heater hos os. Vi mener selv at det er det bedste varmesystem inden for kategorien. Denne brugermanual er udarbejdet så du nemt kan lære at bruge, lærer mere om gas heateren og får mest muligt ud af dens varmemuligheder.


Endnu engang, lad os byde dig velkommen hos os. Vi ser frem til at arbejde med dig i fremtiden.

Enhver innovation eller miniændring uden yderligere varsel.

Samlevejledning:


Samlevejledning

①




Følg pilene i rækkefølgen for at åbne 1. 2. 3. 4.

②




Sidestykkerne fastgøres med de to M4 skruer

③




Bundpladen fastgøres med de fire M5 skruer

④



Vær opmærksom på: Der allerede er to M4 skruer på bagcoveret

⑤



Hjulene sikres med to M8 møtrikker

Tilbehør:

- 2* M4 skruer
- 4* M5 Skruer
- 2* M8 møtrikker
- 4* Hjul
- 2* Skruenøgler

Teknisk Data:

Gas kategori	Gas type	Gas tryk
I3B/P(30)	Butane(G30), Propane (G31) og deres blandinger	(28~30)mbar

Model Nr.	LQ-H002F
Varme input	4200W (306g/h)
Varme styrker	3 levels (4200W/ 2750W/ 1500W)
Elektrisk kraft	420x380x730mm
Pakke størrelse	430x150x710mm
Vægt	N.W/ G.W: 7.5kg/ 9.0kg
Gasslange	Certificeret gaslange i overensstemmelse med EN-standard (anbefalet 50mm)
Gas Regulator	Certificeret i overensstemmelse med EN16129 og i overensstemmelse med lokalregler (flow rate max. 1kg/h)

Tillad masser af frisk luft i rummet, når du bruger heateren. Luk aldrig vinduer og dørene helt, når heateren er tændt.

Dette vil give effektiv varme og en behagelig temperatur.

Keramiske plader aktiveret	Rum størrelse	Ventilations område
1	28 m ³	> 35cm ²
2	55 m ³	> 68 cm ²
3	82 m ³	> 105 cm ²


Sådan bruger du din nye gasovn:

Der er tre ting du skal være opmærksom på ved gasovnen.

Den første er ventilen på gasflasken, som bruges til at tænde og slukke for gassen.

Den anden er gaskontrolknappen, hvor man styrer graderne, her kan man vælge mellem tre indstillinger.

Denne knap er på toppen af gasovnen, se billede nedenfor.



Figur 1.

Det tredje er den piezoelektriske tændingsknappen ved siden af gaskontrolknappen (billedet ovenfor).

Når man trykker på denne knap vil det skabe en gnist på brænderen, således at gassen antændes.

Du kan nu justere varmen ved at indstille knappen på lav, middel og høj.

Installation

1. Sæt gasflasken ind i gasovnen.
2. Installer beskyttelsesremmen så gasflasken ikke kan flytte sig.
3. Tilslut røret til gas ventilen med hættten (vær sikker på der ikke er utætheder).
4. Tilslut den anden del af røret til regulatoren med hættten (vær sikker på der ikke er utætheder).
5. Åben for gasventilen før du bruger gasovnen, derefter luk for gasventilen efter brug.

Tænd gasovnen:

Før du tilslutter regulatoren til gasflasken, tjek om der er en gummiskive på regulatoren og gummiskiven skal være i god stand.

Tilslut regulatoren til gasflasken ved at dreje mod uret på regulatoren.

Åben gasflasken ved at dreje ventilen mod uret. Drej gaskontrolknappen på gasovnen til styrke 1 (lav).

Tryk gaskontrolknappen ned og hold trykket. Dette vil tillade gassen at komme ind til vågeblus og midterbrænderen

Mens du holder presset på gaskontrol knappen, tryk på den piezoelektriske tændingsknap (figur 1) 2 eller 3 gange.

Hver gang du trykker på piezotændningsknappen, vil du høre et klik, samt se en gnist på brænderen.

Når vågeblusset er tændt, fortsæt med at holde gaskontrolknappen nede i yderligere 10-15 sekunder, derved aktiveres flammesvigt sikkerhedsapparatet.

Sluk gasovnen:

For at slukke gasovnen, drej gaskontrolknappen til styrke 1 og luk for gasflasken ved at dreje ventilen på gasflasken med uret. Vær opmærksom på at vågeblus og midterbrænderen er helt slukket.

Test for utætheder (gas):

Hvis du har en mistanke om at der er en utæthed, sluk for gastilførslen og tag gasovnen med til en kvalificeret tekniker der kan kigge på problemet. Forsøg ikke at finde utætheden ved brug af ild. Find det ved at lytte, lokalisere lugten af gas eller brug sæbevand. Hvis der danner sig bobler, betyder det at der er en utæthed.

Sikkerhedsråd:

Flyt ikke gasovnen mens den er i brug.

Placer altid gasovnen så fronten peger mod midten af rummet.

Bruges kun i et godt ventileret rum. Ventilation er nødvendig for at gasovnen fungerer og af sikkerhedsgrunde.

Tillad altid luft at komme ind i rummet, luk aldrig vinduer og dørene helt til.

Undgå at små børn og ældre rører ovnen, den er meget varm.

Det normale beskyttelsesgitter beskytter kun ved tilfældig kontakt med tøj.

Placer ikke tøj eller andre materialer på gasovnen. Hold alt brændbart materiale mindst en meter væk fra gasovnen.

Sluk for gasventilen efter brug.

Hold opløsningsmidler eller dåser med brændbar væske væk fra gasovnen, også selvom ovnen er slukket.

Smid aldrig skrald som f.eks. cigaret skodder i gasovnen, dette kan påvirke ovnen og skabe farlig forurening.

Betjen altid gaskontrolknappen og glasflaskens ventil, ved at stå på siden eller bag gasovnen. Ved at stå foran ovnen udsætter du dig selv for brandfare.

Advarsel:

- Læs brugermanualen grundigt. Den indeholder både vigtig information om hvordan gasovnen fungerer og om hvordan du sikrer din sikkerhed.
- Brug ikke defekte produkter.
- Vedligeholdelse og reparationer skal udføres af en kvalificeret person for at sikre sikkerhed og finde fejl.
- Gem denne manual, hvis der skulle opstå behov for den i fremtiden. Hvis det er nødvendigt kan en ny kopi fås hos din forhandler.
- Sluk for gassen efter brug.
- Produktet passer til en 14.2kg/ 5.5kg LPG-beholder. Når gasflasken skal skiftes: flyt gasovnen til et område der ikke er fyldt med brandbare ting.
- Flyt ikke gasovnen, når den er tændt. Undgå at bøje/dreje gasslangen.
- Placer ikke gasovnen tæt på vægge, gardiner & møbler mens den er tændt. Vend altid ovns front med midten af rummet når den er tændt. Minimum afstand til brandbare elementer fra bagside og sider af gasovne er 1 meter.
- Gasovnen skal testes for utætheder for brug, når gasflasken er blevet tilsluttet efter opfyldning. Brug aldrig en lighter til at teste om der er utætheder.
- Dette er en gasovn uden skorsten. Vær sikker på at rummet er vel ventileret mens gasovnen er i brug. Brug ikke i soveværelset, badeværelset, campingvogn eller ombord på båd.
- Beskyttelsen på dette produkt er der for at forhindre brandfare og brandsår, ingen del af beskyttelse bør blive fjernet permanent. Det giver ikke fuld beskyttelse for børn eller svagelige.
- Gasovnen kræver gasslange og regulator, spørg din lokale forhandler.
- Brug ikke inde i campingvogn eller autocamper.

Skift gasflasken:

Sluk og fjern regulatoren fra gasflasken, Lad gasovnen køle helt af før du fjerner gasflasken og erstatter den.

Forsøg ikke at fjerne regulatoren, mens gasovnen er tændt.

Skift LPG-gasflasken i velventileret område, og væk fra brandbare elementer f.eks. (stearinlys, cigaretter osv).

Vedligeholdelse:

- Hvis gasovnen ikke bliver brugt i en længere periode, f.eks. hen over sommeren, anbefaler vi at holde den overdækket eller placere den i dens kasse for at minimere støv og skidt.
- Vedligeholdelse og rengøring skal foretages mens gassen er slået fra og gasovnen er kold. Forsøg ikke at rengøre ovnen mens den er varm.
- Din gasovn burde blive tjekket årligt af en kvalificeret person, af sikkerhedsårsager for både din og ovns skyld.
- Hvis der opstår problemer med gasovnen i brug, stop med at bruge den og kontakt din forhandler for råd.
- Gør ydersiden, gasflasken og området hvor du opbevarer gasovnen, rent regelmæssigt. Ellers kan det påvirke gasovnens ydeevne.
- Let støvsugning med en blød børste kan fjerne støv på de keramiske elementer. Skrab eller slå ikke disse elementer, da de bliver meget skrøbelige jo mere de bliver brugt.
- Slib ikke på produkterne, for at rengøre gasovnen.

- Hold øje med vågeblus flammen, mens ovnen er tændt. Den burde brænde støt, hvis den flimrer eller har gul spids, bør den blive tjekket om den fungerer rigtigt.
- Hvis en del har brug for at blive erstattet, skal de udskiftes med en original del, som kommer fra fabrikanten. Bliver en forkert eller uoriginal del installeret, kan det være farligt. Samtidig bortfalder garantien.
- Brug ikke en fugtig klud eller få vand på ovnen, mens du rengør. Det kan skabe seriøse problemer med ovnen. Hvis ovnen er blevet brugt på normal vis, kontakt agenter for regulator vedligeholdelse.
- Stil ovnen et rent og tørt sted, når den ikke bliver brugt.

Mobile Gas Heater - Foldable

Usermanual



LQ-H002F

MADE IN P.R.C

Please read the instructions before operating the appliance

Dear Valued Customer:

Thank you for purchasing gas room heater from us. We believe it is the best heating system in similar types.


This instruction manual has been carefully prepared to ensure you will be able to easily operate, learn more about it and fully realize its inherent capabilities.

We invite your comments as well as any issues you may have regarding this manual or our products.

Once again, let us welcome you to be the growing family of our company. We look forward to working with you in the future.

Any innovation or minor changes without further notice.

Assembly Method :



Accessories:

2* M4 Screws

4* M5 Screws

2* M8 Nuts

4* Wheels

2* Wrenches

Technical Data:

Gas Category	Gas Type	Gas Pressure
I _{3B} /P(30)	Butane(G30), Propane (G31) and their mixture	(28~30)mbar

Model No.	LQ-H002A
Heat Input	4200W (306g/h)
Heat Range	3 levels (4200W/ 2750W/ 1500W)
Product Size	420x380x730mm
Package Size	430x150x710mm
Weight	N.W/ G.W: 7.5kg/ 9.0kg
Gas hose	Certified gas hose according to applicable EN-standard and comply with local code (recommend 50mm)
Gas regulator	Certified according to EN16129 and comply with local code (flow rate max. 1kg/h)

Note: Always check up the flexible tube before use. Replace broken or expired hose. The heater shall be always used in draughty room. Allow plenty of fresh air, never seal up the doorways and windows. This will bring efficient combustion and comfortable environment.

Ceramic tiles activated	Room size	Ventilation area
1	28 m ³	> 35cm ²
2	55 m ³	> 68 cm ²
3	82 m ³	> 105 cm ²


Operating Instructions:

There are 3 controls need to be paid attention.

The first is the valve on the cylinder, which will be used to turn ON and OFF the gas supply.

The second is the gas control knob with a dial which has 3 positions marked on it.

This control knob is located on the top end of the heater (fig4)



(fig4)

The third is the piezoelectric ignition button next to the gas control knob (fig4).

Pressing this button will generate a spark on the pilot burner thus igniting the gas to the pilot burner.

The pilot and center burner should remain alight.

You may now adjust the heater setting to Low/Med/High as required.

Installation

1. Put the cylinder into the gas heater
2. Install the protection baffle to make sure the cylinder cant' move
3. Connect the pipe to the gas valve with cap (make sure no leakage)
4. Connect another side of the pipe to the regulator with cap (make sure no leakage)
5. Open the gas tap before using the heater, and close the gas tap after using.

Lighting heater:

Before connecting the regulator to the gas cylinder. Check whether there is a rubber washer on the regulator, and the washer must be in good condition.

Connect the regulator to the gas cylinder by turning the handwheel anticlockwise.

Open the gas cylinder by turning the gas cylinder valve anticlockwise. Turn the gas control knob on the heater to setting 1(fig4).

Press the control knob down and hold in the pressed condition. This will allow gas to flow to the pilot and center burner.

While holding the control knob in the pressed position push the piezoelectric ignition (fig4) button 2 or 3 times. Each time you strike this piezoelectric ignition you will hear a clicking sound as well as see a spark on the pilot burner.

Once the pilot has lit, continue holding the gas control knob in the pressed position for a further 10 to 15 seconds thus activating the flame failure safety device.

Turning off the heater:

To turn off the heater, turn the control knob to position 1 and close the gas cylinder valve by turning the knob on the cylinder clockwise. Ensure that the pilot flame and the center burner are extinguished.

Testing gas leaks:

When you suspect that the heater is leaking, turn off the gas supply and have the unit inspected by a qualified technician. Do not attempt to locate the source of leak with a naked flame. Locate it by sound, smell or by applying soapy water. Any bubbles forming will indicate the whereabouts of a leak.

Safety tips:

Do not move the heater while it is in use.

Always face the heater towards the center of the room.

Use it only in a well-ventilated room. Ventilation is vital for the efficient performance of this heater and for safety of the occupants of the room in which it is being used. Allow plenty of fresh air in, never seal up the doorways and windows.

Prevent young children and elderly people from touching very hot surfaces.

The normal dress guard only protects against accidental clothing contact.

Do not place clothes or other material on the heater. Keep all flammable materials at least one meter away from the heater.

Turn off the gas valve and gas supply after its application.

Never use or store solvents and pressure pack cans near a gas heater –even if the heater is turned off.

Never dispose of rubbish such as cigarette butts in a gas fire-this can affect combustion and produce dangerous pollutants.

Always operate the gas control and cylinder valve from the side or rear of the heater. Standing in front of the heater exposes you to the risk of burns

Warning :

- Read the instructions in the manual carefully. It has important information both for operation use and for your safety.
- Do not use faulty appliances.
- Maintenance and repairs must be carried out by a qualified person only.
- Your heater should be checked manually by a qualified person for safe operation and to detect any fault.
- Retain these instructions for future reference. If necessary, a new copy may be obtained from your Dealer.
- Turn off the gas container valve after use
- The appliance is suitable for 13kg/5kg LPG container, When change gas container, move the appliance to a flame-free atmosphere.
- Do not move the appliance when it operated. Avoid to twist the gas hose.
- Do not place the heater near walls, curtains or furniture while in operation. Always face the heater towards the center of the room when in use. Do not put furniture or other thing in front of the heater; Minimum clearance to combustibles to the rear and sides of the heater is 1000mm.
- This appliance should be leakage tested before initial use and whenever the cylinder has been reconnected after filling. Never use a naked flame to test forleakge.
- This is a non-flue heater. Ensure the room is ventilated while the heater is in operation. Do not operate in a bedroom, bathroom, caravan, boat.
- The guard on this appliance is to prevent risk of fire or injury from burns and no part of it should be permanently removed. It does not give full protection for young children or the infirm.
- This appliance requires a hose and regulator, check with your gas supplier
- Do not use in leisure vehicles such as caravans and auto caravans

Changing the cylinder:

Turn off the regulator and disconnect the regulator from cylinder, allow the heater to control fully before removing and replace the cylinder. Do not attempt to remove the regulator while the heater is still running.

Change LPG cylinder in ample ventilated area, and from any ignition source (candle, cigarettes and so on).

Maintenance:

- When the heater is not in use for a period of time, for instance, over the summer, we recommend that it is kept covered or replaced in its carton to minimize the accumulation of dust dirt that may occur.
- Maintenance and cleaning must be carried out with the gas supply turned off and the heater cold. Do not attempt to clean the heater while it is in use.
- Your heater should be checked annually by a qualified person for safe operation and to detect any faults.
- If any faults are detected in use, stop using the heater and contact your Dealer for advice.
- Periodically clean the exterior and rear cylinder, storage area of your heater to remove dust and lint built-up, which may affect operation of the heater.
- Light vacuuming with a soft brush will remove any dust built-up on the surfaces of the ceramic elements. Do not scrape or knock these elements as they may become very fragile with use.
- Do not use abrasive products to clean the heater.
- Watch the pilot flame while it is in operation. It should burn steadily, if it flickers or is yellow tipped, the heater should be checked for correct operation.
- If any parts need replacement, they must be replaced only with genuine original parts supplied by the manufacturer. The use of incorrect or substitute parts may be dangerous and will void any warranty.